

INSTRUCTION MANUAL FOR EASY IMPLANTING

i-arm PAT.

i-001(Click-in Type)、i-002(Box Type)



i-001(Click-in Type)

1. CUT OFF THE ORIGINAL NOSE PADS BY NIPPERS IF NOT NEED.
2. AFTER CUTTING OFF THE ORIGINAL PADS, FILE AND POLISH THE SURFACE TO MAKE IT CLEAN.
3. CHECK THE DRILL POINTS AND MARK THEM BY AN AWL.
4. USE 1.5MM DIAMETER DRILL BIT AND MAKE THE DRILL BIT BARE AT 3 MM LONG.(REFER TO THE PCT.)



NOTE

(IF DRILL VICE INTERFERES WITH THE FRAMES, LONGER BIT SHOULD BE BARE.)

5. DRILL THE HOLES VERTICALLY ON THE MARKS YOU MAKE IN THE 2 STAGE.
6. REFER TO THE PICS AND HOLD THE ARMS BY OPTIONAL SPECIAL PLIERS.
(RIGHT AND LEFT SHOULD BE DONE IN OPOSITE WAY.)



LEFT



LEFT



RIGHT

7. REFER TO THE PIC AND PUSH IN THE ARMS BY ONE MOTION TAKING CARE OF THE ANGLE OF AMRS.
DO NOT TWIST THE ARMS WHILE PRESSING.



8. DO THE SAME THING AS THE 7 STAGE FOR THE OTHER SIDE.
9. AFTER IMPLANTING THE ARMS, PUT THE NOSE PADS ON ARMS.
10. MAKE THE FINAL ADJUSTMENT CHECKING TO SEE IF THE BOTH ARMS ARE IN THE SAME ANGLE.

 **SUN-RAY CORPORATION**

TOMTOM BLDG 5F 1-16-7, KITAHORIE, NISHIKU, OSAKA 550-0014, JAPAN
TEL (81) 6-6533-2300 FAX (81) 6-6533-2305 E-mail: noriko@sun-rayosa.co.jp